

Bushranger VKS only Whip Frequencies

Frequencies	Station	Tap
14977	VKS 4	7
11612	VKS 3	6
10180	VKS 7	5
8022	VKS 2	4
6845 6796	RFDS Charleville VKS 6	3
5455	VKS 1	2
4010 3995	RFDS Port Augusta Primary VKS 5	1

(VKS channels only)
Bushcomm Part # BU00895

This sheet lists the frequencies that the taps are tuned to on the Bushcomm Bushranger VKS whip. Tap 1 is the bottom tap on the whip.

To select a particular frequency plug one end of the wander lead into the relevant tap, wrap the lead around the whip then plug the other end into the bottom tap. If you want to tune to the lowest frequency then remove the wander lead altogether, but remember to store it in a safe place for later use.

A Quality product
MADE in AUSTRALIA